FREElift eTouch
by Kesseböhmer

Quick guide

KESSEBÖHMER
CLEVER STORAGE

Programming with push and click



push — Press the button and hold until confirmation sound (~ 2 s)

click — Press the button and release immediately

Power supply



Initial teaching



Front-cleaning mode



FREElift eTouch
by Kesseböhmer

Quick guide

KESSEBÖHMER
CLEVER STORAGE

Initial teaching







Optional functions

parallel





across corner





new reference run







reset



Front-cleaning mode